

## APPENDIX B

### INCOMPATIBLE CHEMICALS<sup>1</sup>

<u>Chemical</u>	<u>Keep out of Contact With:</u>
Acetic Acid	Nitric acid, hydroxyl compounds, ethylene glycol, perchloric acid, peroxides, permanganates
Acetylene	Chlorine, bromine, copper, fluorine, silver, mercury
Alkali Metals	Water, carbon tetrachloride or other chlorinated hydrocarbons, carbon dioxide, the halogens
Ammonia, Anhydrous	Mercury, chlorine, calcium hypochlorite, iodine, bromine, hydrofluoric acid
Ammonium nitrate	Acids, metal powders, flammable liquids, chlorates, nitrites, sulfur, finely divided organic or combustible materials
Aniline	Nitric acid, hydrogen peroxide
Bromine	Same as chlorine: ammonia, acetylene, butadiene, butane, methane, propane (or other petroleum gases), hydrogen, sodium carbide, turpentine, benzene, finely divided metals
Butyl lithium	Water.
Carbon, activated	Calcium hypochlorite, all oxidizing agents
Chlorates	Ammonium salts, acids, metal powders, sulfur, finely divided organic or combustible materials
Chromic Acid	Naphthalene, camphor, glycerin, turpentine, alcohol, flammable liquids in general
Chlorine	Same as bromine: ammonia, acetylene, butadiene, butane, methane, propane (or other petroleum gases), hydrogen, sodium carbide, turpentine, benzene, finely divided metals
Chlorine dioxide	Ammonia, methane, phosphine, hydrogen sulfide
Copper	Acetylene, hydrogen peroxide
Cumene hydroperoxide	Acids, organic or inorganic
Cyanides (Na, K)	Acids
Flammable liquids	Ammonium nitrate, chromic acid, hydrogen peroxide, nitric acid, sodium peroxide, halogens, other oxidizing agents

---

<sup>1</sup> From Manufacturing Chemists' Association, Guide for Safety in the Chemical Laboratory, pages 215-217.

Appendix B – Incompatible Chemicals

Hydrocarbons	Fluorine, chlorine, bromine, chromic acid, sodium peroxide
Hydrocyanic acid	Nitric acid, alkalis
Hydrofluoric acid	Ammonia, aqueous or anhydrous
Hydrogen peroxide	Copper, chromium, iron, most metals or their salts, alcohols, acetone, organic materials, aniline, nitromethane, flammable liquids, oxidizing gases
Hydrogen sulfide	Fuming nitric acid, oxidizing gases
Iodine	Acetylene, ammonia (aqueous or anhydrous), hydrogen
Mercury	Acetylene, fulminic acid, ammonia
Nitric Acid	Acetic acid, aniline, chromic acid, hydrocyanic acid, hydrogen sulfide, flammable liquids, flammable gases
Oxalic acid	Silver, mercury
Perchloric acid	Acetic anhydride, bismuth and its alloys, alcohol, paper, wood, sulfuric acid, organics
Potassium	Carbon tetrachloride, carbon dioxide, water
Potassium permanganate	Glycerin, ethylene glycol, benzaldehyde, sulfuric acid
Silver	Acetylene, oxalic acid, tartaric acid, ammonium compounds
Sodium	Carbon tetrachloride, carbon dioxide, water
Sodium peroxide	Ethyl or methyl alcohol, glacial acetic acid, acetic anhydride, benzaldehyde, carbon disulfide, glycerin, ethylene glycol, ethyl acetate, methyl acetate, furfural
Sulfuric acid	Potassium chlorate, potassium perchlorate, potassium permanganate (or compounds with similar light metals, such as sodium, lithium, etc.)